

First Time Set-Up Instructions



Take a new Drain Insert and place it in the waste trap.



Press down on the drain insert until you feel and hear a slight popping sound. The insert must be tight.



Pour about 30 oz. of water over the Drain Insert. Then slowly pour the *entire contents of the Odor Barrier* onto the Drain Insert. Wipe clean. The ZeroFlush Urinal is now ready for use.

Daily Cleaning Instructions



Remove debris.



Spray and wipe down



Wipe clean.