



## ECOS DRYWALL SPACKLE/FILLER POWDER APPLICATION INSTRUCTIONS

<b>Recommended For</b>	Filling small or large cracks, small holes, and joints.
<b>Coverage</b>	400 sq. ft. per gallon   100 sq. ft. per quart; 1 coat recommended
<b>Description</b>	Drywall Spackle/Filler Powder is the ideal filler for small or large cracks, small holes, joints and a variety of similar jobs. The white powder mixes easily to a smooth consistency, which dries to an easy to sand finish. Special binders give excellent adhesion. This product must be used in conjunction with ECOS Filler Sealer.
<b>Preparation</b>	Ensure crack or hole is dry and free from loose or dusty material. Touch up any nails and screw heads with two-coats of ECOS Stainblock, to avoid rust staining. <b>WARNING:</b> Older buildings may contain lead-based paint, which requires professional remediation if it is disturbed. If in doubt, consult with a professional from a Lead-Safe Certified Firm.
<b>Application and Clean Up</b>	Add 2 parts Filler with 1 part water (approx) and mix to a smooth paste. The filler is ready for use in about one minute and remains workable for more than 20 minutes. Press filler paste into hole with a filling knife/trowel. Fill the hole slightly proud, or slightly higher than the surface, for sanding purposes. Sand, when fully dry, to a smooth flat surface and brush/wipe free of dust. Special easy sand formula! Normally sets fully in around 1 to 2 hours. Before painting, seal with one coat of ECOS Filler Sealer and allow to dry fully. Clean bowl and tools with warm water. Do not wash excess material into drains, but allow it to dry on paper, then dispose of as household trash.